



Quick Start Instructions for Bubble Waffle Machine



- **Unpack Machine and remove any papers or packing material**
- **Plug in machine, attach handle, open the plates and flip the switch. Adjust Temp knob to preferred temp. Usually around 333 to 350 F**
- **Machine is now preheating.**
- **Green light on machine will turn off once preheated**
- **Pour your bubble waffle batter and set the time for 3 minutes.**
- **Carefully open your machine and remove your finished product.**